
## INSTALLATION

- 1. Drive the driving nut ⑤ into guitar body.
- 2. Put stud bolt ⑥ into driving nut ⑤ with adjustment of locking screw ⑦ located in stud bolt ⑥ not to come out from the bottom of stud bolt ⑥.
- 3. Loosen the moving screws ③ and ④ respectively and put the bridge on to stud ⑥. Then tighten the moving screws ③ and ④.



## I . Up-and-down adjustment

Loosen the locking screw ⑦ located in the stud bolt ⑥ and also loosen the adjust screw ③ then adjust the main body up and down. When finished, be sure to retighten the screws ⑦ and ③.

- ${\rm I\hspace{-.1em}I}$  . Back-and-forth adjustment
  - 1. To adjust to forth, loosen the moving screw ④ on left and right, then tighten the moving screw ③ on both sides.
  - 2. To adjust to back, loosen the moving screw ③ on left and right, then tighten the moving screw ④ on both sides. Be sure the screws ③ and ④ stay tight without any rattling when finished.

Note: In either case 1 and 2, do it right and left in turn little by little as you may break a movable part if one side only is moved a lot.

It is available for move 1.5mm from center to back and forth.

## III. Intonation adjustment

To adjust saddle position, loosen the locking screw (9) and move the saddle by adjusting screw (8). Be sure to retighten the locking screw (9) after finished.